
# Parts Provided with the ECA-TZ-29 and ECA-TSS-29 Extension Collar

**Extension Collar** 




\* Bolts (4), Stainless Steel Nuts (4) & Washers (8) provided for bolting the two sections of the ECA together.

 $\cdot$  Washers (4), Brass Nuts (4), and Spacers (4) provided for bolting the combined ECA to the Trapzilla.


WARNING: PROPER INSTALLATION INSTRUCTIONS MUST BE FOLLOWED FOR THERMACO WARRANTY TO BE VALID. MAXIMUM INSTALLATION DEPTH PERMITTED FOR TRAPZILLA GREASE INTERCEPTORS AND SOLIDS SEPARATORS IS 60" MEASURING FROM CENTER OF INLET TO SURFACE. ANY INSTALLATION DEEPER THAN THIS VOIDS THE WARRANTY FOR THE UNIT. CONTACT THERMACO REGARDING INSTALLATIONS EXCEEDING THIS DEPTH.

#### Trapzila





The extension collar height as calculated on page 2 determine the steps required to complete the extension collar installation. The ECA-TZ-29 as shipped is naturally adjustable between 17" and 30.5" in height. The following page (page 4) gives instructions for connecting the two collar halves. The remaining pages cover height adjustments.



If the calculated height (page 2) is between 17" and 30.5" inches please use page 5 of these instructions for setting the collar height.


If the calculated height is between 5-1/2" and 17" then the collar must be trimmed to match the calculated height. The minimum height for this collar assembly is 5-1/2". If the calculated height is less than 5-1/2", the finished grade level must be adjusted to match either the original Trapzilla cover position or the position with the 5-1/2" extension, or a ECALA-TZ-18 (ECALA-TSS-18 for TSS Models) may be purchased to meet calculated heights less than 5 1/2". Please follow the instructions on page 6 for trimming the collar. After trimming follow the instructions on page 5 for assembly.

If the calculated collar height is greater than 30.5 inches then multiple collars must be used. The multiple collars may be a combination of adjusted (page 5) and/or trimmed collars (page 6). Whenever possible use only the adjusted method for the best installation. Because of the "nesting" aspect of these collars, it is necessary to add 1-1/2" to the height of each additional collar (after the first one). (i.e. for 24" of calculated extension height collars of 13-1/2" and 12" could be used.) Follow the instructions on page 5 for assembly of multiple collars.

Use silicone sealant (not provided) to seal all joints to ensure a watertight installation.

#### Trapzila ATHERMACO<sup>®</sup> Technology

**Bolting the Upper and Lower Pieces Together** 



Copyright ©2014 Trapzilla<sup>®</sup> Thermaco, Inc. • P.O.Box 2548 • Asheboro, NC 27204 • Toll Free: (800) 565-3569 V: (336) 629-4651 • F: (336) 626-5739 • info@thermaco.com • www.trapzilla.com

## Setting the Adjusted Collar Height

Figure 1

1) Extend the collar to match the calculated height as determined on page 2.

2) Unscrew the brass nuts and remove the 22" Diameter Cover from the Trapzilla unit.

3) Using the instructions found on page 4, bolt the two pieces of the Extension Collar together. Use Silicone Sealant (not provided) to seal the space between the two sections of the collar.

4) Mount the assembled ECA collar to the Trapzilla unit. Use four (4) brass nuts, washers, and bushings (provided with the ECA) to mount the collar to the Trapzilla unit. Using the corresponding bolts in the Trapzilla top and the holes in the collar. Use Silicone Sealant (not provided) to seal the space between the collar and the Trapzilla unit. **See Figure 2** 

5) Replace the Trapzilla cover to the extension collar and replace the washers and nuts removed in step 2.

9


Figure 2

П İNLET



Copyright ©2014 Trapzilla<sup>®</sup> Thermaco, Inc. • P.O.Box 2548 • Asheboro, NC 27204 • Toll Free: (800) 565-3569 V: (336) 629-4651 • F: (336) 626-5739 • info@thermaco.com • www.trapzilla.com

# **Trimming the ECA Extension Collar**



# When trimming the ECA Extension Collar, ALWAYS:

- 1) Measure from the Top of the Lower (Outer) section & cut the top of the section.
- 2) Measure from the Bottom of the Upper (Inner) section and cut at the bottom of the section.
- The amount to be trimmed from each piece is equal to 17" minus the calculated height.
  i.e. If the calculated necessary height is 7", 10" should be trimmed from each half. (17"-7"=10").
- 4) If necessary, cut out notches on the upper section where the bolts will align to ensure that the inner piece will fully rest on the lip of the lower section.

###